

# SNF RRAM Standard Process Flow and Characterization of Lesker-2 TiN

ENGR241 WEEK 3 END-WEEK UPDATES

**Project Members:** Akash Levy, Jung-Soo Ko


**Staff Mentors:** Michelle Rincon, Vijay Narasimhan, J Provine, Usha Raghuram

# Aim & Goals

- Test and characterize ALD RRAM devices
- Develop TiN recipe on new Lesker with low oxygen contamination
- Compare TiN properties (composition, resistivity, topography)
- Make electrical/imaging data and test structure layouts available to SNF
- Make SOPs for RRAM stacks and report TiN findings



Process Flow  
Development



Parameter  
Optimization



Comprehensive  
Documentation



SNF  
Database

# Tool Training Update

- ✓ XPS qualification
- ✓ Refresher on PT-Ox/PT-MTL
- ✓ Wet bench: wbflexcorr
  - For sidewall/oxide/resist cleaning process

Need a bit more characterization:

- ☐ Prometrix
- ☐ Nanospec
- ☐ P2




# TiN Sample Preparation & Characterization

(Not drawn to scale)




**Compare 3 sputtering tools:** Lesker-1 (SNF), Lesker-2 (SNF), AJA (non-SNF)


Prometrix Resistivity




XPS/Auger Composition



AFM Surface Roughness



AFM Step Height



Measure 3-4x throughout quarter to quantify oxidation over time

Stanford University

# Progress Updates: Fabrication

- ✓ RCA clean wafer
- ✓ Woollam to measure native oxide thickness (11.2Å)
- ✓ Dry oxide growth for 1hr in thermco4 @ 1100°C (~100nm)
- ✓ Woollam to confirm final oxide thickness (~1062.54Å, ~1052.91Å)
  - › Exact thickness is not important, just there to insulate TiN from Si
  - › Good quality oxide is important to get accurate TiN surface roughness

## ☐ Sputter 30nm TiN (Kapton tape for step)

✓ AJA (non-SNF)

☐ Lesker-1 (SNF)

☐ Lesker-2 (SNF)

## ☐ AJA Characterization

✓ XPS

☐ Prometrix

☐ AFM

## ☐ Lesker-1 Characterization

## ☐ Lesker-2 Characterization



**Update:** Lesker-2 expected to go live in early Feb.

Underlined is planned to be done by Tuesday



Lesker TiN target  
Stanford University


# AJA TiN Sputter Recipe: Reactive Sputtering

- **Target:** Ti
- **RF Power:** 200W
  - 150W also ok; different dep rates
- **Wafer Bias:** 100V
  - DC bias 92-94V on AJA in practice
- **Ar Flow:** 30 sccm
- **N Flow:** 3 sccm
  - Unit conversion means that this is written as 30 on AJA somehow
- **Set Pressure:** 2.15 mTorr
  - 1.8-1.9 mTorr on AJA in practice


## Recipe:

- Load sample and wait for  $1\text{e-}7$  base chamber pressure
- Plasma on another target (conductive) e.g. Al, GeTe
  - Eases plasma ignition for TiN target
- Plasma on Ti target
  - Bias on other target off
- 20s ramp-up of Ti target RF power
- 2 minutes pre-sputtering of Ti target (shutter closed, no wafer bias)
- 20s ramp-up of wafer bias
- Open shutter and deposit for X seconds
- Close shutter
- 20s ramp-down of Ti target RF power


# AJA XPS Results: Surface Survey Scan



# AJA XPS Results: Hi-Res + Depth Profile



Temp01202020\_TiN\_AJA.5.First Point\_1\_InProgress.pro: First Point  
2020 Jan 23 Al mono 50.2 W 200.0  $\mu$  45.0° 55.00 eV  
4.2590e+003 max  
Si2p1







# AJA XPS Results: Fitting

Ti fit has spin-orbit splitting that causes doublet peaks

Chemical state	Binding energy $Ti_{p_{3/2}}$ / eV
Ti metal	454.1
TiN	454.9
TiO <sub>2</sub>	458.5



TiN\_AJA\_HiRes\_Top\_Ti\_fit\_1.spe: First Point  
2020 Jan 23 Al mono 50.2 W 200.0  $\mu$  45.0° 55.00 eV  
Ti2p org 1/1  
2.9263e+004 max  
Stanford Univer  
38.40 s




- Ti2p peak has significantly split spin-orbit components ( $\Delta_{\text{metal}}=6.1\text{eV}$ ). Splitting -value varies with chemical state ( $\Delta_{\text{nitride}}=6.0\text{eV}$ ,  $\Delta_{\text{oxide}}=5.7\text{eV}$ ).
- Typically FWHM for each spin-orbit component is the same, but for Ti2p the  $Ti_{2p_{1/2}}$  component is much broader than the  $Ti_{2p_{3/2}}$  peak. Consequently,  $Ti_{2p_{1/2}}$  peak is much shorter than expected.
- Caused by Coster-Kronig effect. (Post-ionization,  $Ti_{2p_{1/2}}$  state is very short lived compared to  $Ti_{2p_{3/2}}$  state.)
- Causes difficulty in accurately peak fitting Ti2p region with multiple chemical states

# Lesker: Which Recipe? Discussion

- TiN isn't used that often in Lesker
- My original plan:
  - › Master Recipe on Src 2 (TiN source) with downstream control
    - 35 -> 5 sccm Ar to allow plasma to ignite
    - No other sputtering gases
  - › Didn't have enough time to run recipe 😞
- Paul Comita recipe: Ti/TiN co-sputter for higher Ti concentration
- Other recipes call for 3 to 5 sccm Ar with TiN target
- Should I try to work with Maurice to replicate the AJA recipe on Lesker-1?
  - › XPS shows that it works super well in producing low-oxygen TiN
  - › May not even need Lesker-2 to do good-quality TiN

# RRAM Process Flow Outline

(Not drawn to scale)



# Process Flow Parameters


- **Resistive switching material (metal oxide):** hafnia
- **Seed layer:** none
- **Dimensions:**
  - › **TiN electrode thickness:** 30nm
  - › **Resistive switching layer thickness:** 10nm
  - › **Device size:** {1, 2, 3, 4, 5, 8, 10, 20, 40, 50} um
- **RS oxide growth temperature:** 250C
- **Annealing:** none
- **Metal oxide ALD method:** thermal
- **TiN deposition method:** sputtering
- **Top contact:** TiN only

# Progress Updates



Underlined is planned to be done by Tuesday

- ✓ RCA clean wafer
- ❖ Deposit 10nm Ti with AJA (skipped)
- ✓ Deposit 30nm Pt with AJA
- ✓ Deposit 100nm SiO<sub>2</sub> with AJA
- ✓ Woollam to check oxide thickness (834Å)
- ☐ Photolithography
  - ☐ YES Oven for 30 mins
  - ☐ SVG Coat 2 with 1µm Shipley 3612 resist, 2mm EBR, skip prime step
  - ☐ Expose with Heidelberg: look at previous runs, logbook, exposure charts by tool (dose: 80, defoc: ±2)
  - ☐ SVG Develop (1µm 3612 dev) w/post-exposure bake and inspect
- ☐ PT-Ox: Oxide ER Test, 1 min
- ☐ Nanospec to check etching
- ☐ Matrix for resist ashing: use defaults
- ☐ (Strip.rcp 120s) and inspect to see if resist is removed
- ☐ Metal cleaning on wbflexcorr
  - ☐ SRS-100 for stripping photoresist from metal wafers, 60C
  - ☐ PRS-1000 for final metal clean before deposition or furnace step, 40C
- ☐ Fiji1 thermal HfO<sub>2</sub>: 100 cycles standard recipe
- ☐ Woollam to check oxide thickness
- ☐ TiN deposition 30nm
- ☐ Photolithography (see previous)
- ☐ PT-MTL: still need details
- ☐ Microscope to check etching
- ☐ Matrix for resist ashing (see previous)
- ☐ Metal cleaning on wbflexcorr (see previous)

# Layout Generator



# Layout Generator



**Finalized layout:** alignment marks, tiling, centering about origin to make Heidelberg usage easier  
**Design dimensions:** about 4cm x 4cm, (20x3 array) x (4x2 grid) devices per size with 10 device sizes

**Thank you!**

QUESTIONS?

